

UTTERMOST

ASSEMBLY INSTRUCTIONS

21613

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING FIXTURE.

We suggest a licensed electrician for all fixture installations.

Installation Steps

1. Carefully unpack your new fixture and lay out all the parts on a clear surface.
2. Thread the Mounting Screws into the matching holes of the Mounting Bar, and tighten with the Hex Nut. Thread the Ground Screw (Green) into the Mounting Bar. Secure the Mounting Bar to the Outlet Box with the Outlet Box Screws. Thread the Nipple into the Mounting Bar center hole.
3. Adjust the length of wire needed for your installation, by loosen the plastic screw on the connector. Adjust to desired length and screw on the plastic screw. Remove excess wire.

Make Wire connections with Wire Connectors:

-- The smooth wire (w/ marking) from fixture to Black Wire from power source.

--The ribbed wire (w/o marking) from Fixture to White Wire from power source.

--Attach the Ground Wire and house ground wire to the Mounting Bar with the green Ground Screw.

Carefully tuck wires back into the Outlet Box.

4. Place the fixture Canopy up to the ceiling over the Nipple and use the plastic Connector to tighten the Canopy onto the Nipple until the assembly is secure.
5. Install the light bulb in accordance with the fixture's specifications. DO NOT EXCEED THE MAXIMUM WATTAGE RATING.
6. Turn on the power at fuse or Circuit Box.

NOTE: It will take a few days for the fixture to relax to hang straight due to the unique wire and compressed packaging.

