



Item#06655

UTTERMOST

Assembly Instructions

1. Take all parts out of carton carefully, and place it on a flat surface.

2. Screw four parts tightly together as photo A,B,C,D.,
Then hang the clock frame in the wall.

3. Put the cardsheet with a hole as photo E, where the clock
works hang in the center.

4. See the photo F .

