



UTTERMOST

## STYLE NO. :21231 Parts and Hardware List

A.	Chain	5 FEET
B.	Screw Collar Loop	1PC
C.	Canopy	1PC
D.	Screw(8/32*1")	2PCS
E.	Cross Bar	1PC
F.	Green ground screw	1PC
G.	Wire Nuts	3PCS
H.	Quick Link	2PCS
I.	Nipple	1PC

Please make sure that you have all the parts indicated before you begin assembling this item.

Please read Wiring instructions before you begin assembling and installing your Chandelier lamp.

**WARNING:BEFORE INSTALLING:** make sure the electricity supply is shut off to avoid a possible electric shock.

## Assembly Instruction

1. Take the parts carefully out of the carton, place them on a flat surface, and make sure that the parts will not be damaged.
2. Attach the Cross Bar to the Outlet box by using two 8-32 Screws (See Figure 1)
3. Install the supply ground wire in the Cross bar with the Ground Green screw.
4. Place the null wire, ribbed black and white wire evenly against the ribbed Black and white wire from the outlet box and place the live Black and white wire, smooth Black and White wire evenly against the smooth Black and White wire from the outlet box.  
(Connecting the wires - See Figure 2)
5. After the wires are connected, carefully place them inside the Outlet Box.  
(See Figure 1)
6. Fasten the Cross Bar to the outlet box by using the outlet box 8-32 Screws.
7. Insert the Nipple into the pre-drilled hole in the Cross bar and secure with the washer and Hex Nut.
8. Attached the screw collar loop to the exposed of the nipple and secure by turning in a clockwise direction.
9. Attach the quick link to the chain, then slip the screw collar nut first and then place the Canopy over the other end of the chain to Screw Collar Loop.
10. Attach the other quick link on the other end of the chain to the loop on the top of Chandelier Assembly.
11. Place Canopy over the outlet box and secure with screw collar nut.
12. Screw the Loop (A) to the Nipple (K), and secure the Ball nut (J) to the exposed Nipple until secure.
13. There are 3 Arms of this lamp, and please unfold two of the Arms and make sure the space between the two arms are same.
14. Screw the Tube C to the finial (D) and place the Disk (B) to the bottom of (I), then secure with Tube C. Attach the Disk (E), Finial (D) to the exposed of Tube C and secure by turning in a clockwise direction.
15. Place the Seeded Glass Shade (F) onto the Socket, then secure with Ring (G) until tight. Repeat this step to install another two Seedy Glass Shades into the Sockets.
16. Install 3\*100 Watt Type A bulls(Bulls not included) into the sockets of the fixture.
17. And the Assembly is complete.



UTTERMOST

