

# UTTERMOST

## ASSEMBLY INSTRUCTIONS

### STYLE#: 21328

*Carefully unpack all lamp parts from the carton.*

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is turned off. This lamp must be installed on reinforced Outlet Box.
3. Fasten the **Cross bar** to the **outlet box**. Secure the **Nipple** onto the **Canopy** with **Loop #1**.
4. Adjust chain length as needed. Thread **Quick Link#1** into **Loop #1** on the Canopy, then **Quick Link #2** into Loop #2 on the **Lamp Body**. Hand tighten until snug.
5. Pass the supply wires through the **Canopy** and the hole in the middle of the **Cross Bar**.
6. The power supply wire consists of three wires, one black wire, one white wire and one silver ground wire.  
Connect the wires as shown.**A.**Connect the House Ground Wire to the Fixture Ground Wire.  
**B.**Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side).  
**C.**Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side).  
**D.**Wrap each connected wire with Wire Connector and carefully stuff all of the connected wires into the Outlet Box.
7. Put the **Glass Shade** onto the **Shade Base** separately with care.
8. Install the correct **Edison Bulb** (Not Included) onto the **Socket** referring to fixture markings and/or labels for maximum wattage.

**Your installation is completed now. Restore electricity.**

