



UTTERMOST

ASSEMBLY INSTRUCTIONS

ITEM # : 21871

**IMPORTANT : TURN OFF THE POWER AT THE MAIN FUSE
OR CIRCUIT BREAKER BOX
BEFORE STARTING INSTALLATION**

Carefully unpack and identify all parts before assembly.

1. Install screw(E) onto the wall
2. Thread the screw (F) into the canopy and screw with ball finial (A)
3. Install glass shade(C) onto threaded sockets (B) by fastening counter rings(D)
4. Install bulbs(not included). See relamping label located at socket area for type and maximum allowed wattage.

