

UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE#: 22038

Carefully unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is power off
3. Thread Rods and shade assembly together, tighten until snug.
4. Place the Ceiling Canopy over the Mounting Screw and thread Mounting Ball onto the Mounting Screw to secure it, Hand tighten until snug.
5. Thread the G125 Edison Bulb (Not Included) onto the Socket. Hand tighten until snug

