



UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE#: 22166

Carefully unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is power off.
3. Using 2pcs of Outlet Box Screws, fasten the **Universal Bar** to the Outlet Box. Then Secure the Canopy to the **Universal Bar** with the **Mounting Balls**, making sure that the **balls** are fully threaded onto the **Mounting Screws** before tightening.
4. Determine the number of **Rods** to be assembled according to your hanging height. Pass supply wires through the **Rods**. Thread the **Rods** to connect **Nipple#1** and **Nipple#2** of **Fixture Body**. Hand tighten until snug.
5. Pass the supply wires through the **Canopy** and the hole in the middle of the **Universal Bar**.
6. The power supply wire consists of three wires, one black wire, one white wire and one silver ground wire.
 - A. Connect the House Ground Wire to the Fixture Ground Wire.
 - B. Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side).
 - C. Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side).
 - D. Wrap each connected wire with Wire Connector and carefully stuff all of the connected wires into the Outlet Box.
7. Install the correct **Edison Bulb** (Included) onto the **Socket** referring to fixture markings and/or labels for maximum wattage.
8. Place the **Glass shade** over the **metal Plate**. And Position the **nipple#3** through the hole on the **Metal Plate**. Turn the **Metal Finial** onto the **Nipple#3** to secure it. Hand tighten until Snug.

Your installation is completed now. Restore electricity.



