

STYLE NO:22442

Parts and Hardware List

A	Sconce Assembly	1PC
B	Shade	1PC
C	Universal bar	1PC
D	Mounting Screws	2PCS
E	Wire Nut	2PCS
F	Ball Nuts	2PCS
G	Green Screw	1PC
H	Outlet box screw	2PCS

**Please make sure that you have all the parts indicated before you begin assembly of this item**

**Please read Wiring Instructions before you begin assembling and installing your Wall Sconce**

**WARNING: BEFORE INSTALLING** Make sure electricity supply is shut off to avoid a possible electric shock

### **Assembly Instructions**

- 1. Carefully remove the parts and hardware from the carton.**
- 2. Fasten the universal bar to the outlet box by using two screws supplied with the outlet box .**
- 3. Install the ground wire in the universal bar with the green screw supplied.**
- 4. Place the white ,ribbed or tinted wire evenly against the white wire from the outlet box and place the black,smooth or un-tinted wire evenly against the black wire from the outlet box .(Connecting the Wires-See Figure2).**
- 5. After the wires are connected,tuck them carefully inside the outlet box ,Place Canopy over the outlet box and secure with Ball Nuts.**
- 6. Attach the shade onto the socket of Arm Assembly using the Socket Ring .See Illustration.**
- 7. Install 60 Watt,Type B bulbs (sold separately) into the sockets of the fixture.**

