




ASSEMBLY INSTRUCTIONS

STYLE# 29689-1

Careful unpack all Assembly parts from the carton.

1. Place the **lamp base** in an upright position on the floor.
2. Place the **Glass** on the correct position on the top of the lamp, hole to hole, and thread the **Finial A with nipple** onto the hole, then thread the **Finial B** to Secure the **Glass**, hand tighten until snug.
3. Install the **Edison Bulb**(Included) onto the Socket before connecting the plug to the electricity outlet Box.



INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet on one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not contact a qualified electrician. Never use an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.