

UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE#: 30485

Carefully unpack all Assembly parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.

2. Insert the **Part A** into the top of the **Base** while pulling excess cord where it exits the **Base**. Attach **Flat Washer** and **Hex Nut** to the threaded rod of **Part A**. The **Flat Washer** and **Hex Nut** are pre-positioned on the cord. Tighten the **Hex Nut** by using **Wrench** enclosed in the parts bag.

3. Thread **Part C** into **Part B** by turning **Part C** clockwise to tighten until snug.

4. Install **Shade** onto fitters by fastening counter rings onto threaded **Socket**. Located the **Socket Collar** with the **Plastic Wrench** to the **Socket** and hang it tight.

5. Install correct Bulbs referring to fixture markings and/or labels for maximum wattage. (Not Included)

IMPORTANT SAFETY INSTRUCTIONS

This Floor lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

