

# REVELATION

by UTTERMOST

## ASSEMBLY INSTRUCTIONS

STYLE#: **R18982**

**Carefully unpack all Accessory parts from the carton.**

1. Take all parts carefully out of the Carton, and place all parts in an upright position on the floor.
2. Place **Pipe** with **Handle** through the hole of **Plastic washer A** and **Glass**.
3. Place the **Plastic washer B** on the threaded **Pipe**, then turning clockwise to tighten the **Knobs**, hand tighten until snug.

