REVELATION ASSEMBLY INSTRUCTIONS

STYLE#: R21340

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

Carefully unpack all lamp parts from carton. We suggest a licensed electrician for all fixture installations.

- 1. Take the lamp carefully out of the Carton, and place on a flat surface.
- 2. Be sure power to the installation point is OFF.Follow the steps below for assembly.
- **3**. Determine the number of Rods for assembled to the Fixture Body as needed to hang at your determined height. Adjust the length of wire needed for your installation leaving extra for wiring to the box, remove excess. Pull the Supply Wire with Ground Wire through the selected **Rods** and **Swivel**. Thread the **Rods** & connect **Metal Shade** and **Part A**. Hand tighten.

4. Pass the supply wire through the Universal Bar assembly, secure the Universal Bar to the Outlet Box with Outlet Box Screws.

5. Connect the wire as shown.

a.Connect the House Ground Wire to the Fixture Ground Wire, secure with wire nut.

b.Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side), secure with wire nut.


c.Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side), secure with wire nut. **d.**Carefully stuff all of the connected wires into the Outlet Box.


6. Thread Crystal Finials (Big Size) into Ball #A by turning Crystal Finials(Big Size) clockwise to tighten until snug.

7. Thread Crystal Finials (Small Size) into Ball #B by turning Crystal Finials(Small Size) clockwise to tighten until snug.

8. Install the correct Bulbs (Bulbs Not Included) into the Socket until snug.

Your installation is completed now. Restore electricity.





P.O. Box 558 | 3325 Grassy Hill Road | Rocky Mount, VA | 24151 www.uttermost.com/Revelation