

REVELATION

by LUTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE# R21520

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

Carefully unpuck all lamp parts from carton. We suggest a licensed electrician for all fixture installations.

1. Take the lamp carefully out of the Carton, and place on a flat surface.
2. Be sure power to the installation point is OFF.
3. Pull the power supply wire out from the outlet box and mount the **Universal Bar** to the outlet box with **Outlet Box Screws**.
4. Assembly Fixture Body as following:
 - Step 1. Take the **Leather Shade** place on a flat surface. Then put **Metal Ring** on the top of **Leather Shade**.
 - Step 2. Place **Part D** onto **Leather Shade**. Take the bottom of **Part B** into **Part C** and secure with **Screw #2**. Tighten until snug.
 - Step 3. Take the top of **Part B** into **Part A** and secure with **Screw #1**. Tighten until snug.
 - Step 4. Fixture Body assembly is complete.
5. Adjust the length of wire needed for your installation, remove excess. Determine the number of **Rods** to be assembled to the **Fixture Body** as needed for your hanging height. Pull the **Supply Wire** with **Ground Wire** through the selected **Rods** and **Swivel**. Thread the **Rods & connect Nipple**. Hand tighten.
6. Connect the wire as shown.
 - a. Connect the House Ground Wire to the Fixture Ground Wire, secure with wire nut.
 - b. Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side), secure with wire nut.
 - c. Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side), secure with wire nut.
 - d. Carefully stuff all of the connected wires into the Outlet Box.
7. Place the **Canopy** over the **Mounting Screws** and secure with **Mounting Balls**. Hand-tighten until snug.
8. Install the correct Edison **Bulb** (Included) into the **Socket** until snug.

Your installation is complete. Turn electrical power back on.

