

REVELATION

by UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE# R22113

Carefully unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface. Take care NOT to break the Socket.
2. Be sure the power to the installation point is off. This lamp must be installed on reinforced Outlet Box.
3. Please assemble the lamp as the following pictures.

Picture #1: Put the **Upper Shade Frame** with a hangtag "A" upside down on a flat surface. Take care NOT to break the **Socket**. Then put **Glass Shade #1** into the **Upper Shade Frame** with care.

Picture #2: Put the **Metal Ring** onto the **Upper Shade Frame**. Make sure **Hole #1** on the **Upper Shade Frame** and **Hole #2** on the **Metal Ring** are lined up.

Picture #3: Put **Glass Shade #2** onto the **Metal Ring**. Be careful NOT to break the glass.

Picture #4: Put the **Bottom Shade Frame** with another hangtag "A" onto **Glass Shade #2**. Pay attention to match the arm with mark "A" on the **Bottom Shade Frame** with the arm with mark "A" on the **Upper Shade Frame**. At the same time let **Hole #3** on **Bottom Shade Frame** in the same line with **Hole #1** and **Hole #2**.

Picture #5: Thread the **Screw** into **Hole #1**, **Hole #2** and **Hole #3**, then secure it with the **Nut** then decorate it with the **Ball Finial** from the inside of the shade. Thread the other two **Screws** on the shade frame the same way to put **Upper Shade** and **Bottom Shade** together.

Picture #6: Put the whole **Shade**, say the **Lamp Body** upside. Be careful NOT to break the glass. Then thread the **Rod** onto the **Nipple**.

Picture #7: Use **Quick Link #1** to connect the **Loop** and **Chain**, then **Quick Link #2** to connect the **Chain** and **Canopy**.

4. Pull the wire from the **Canopy**, then the center hole in the **Universal Bar**. The power supply wire consists of three wires, one black wire, one white wire and one green ground wire.
5. Connect the wires as shown :
A. Connect the House Ground Wire to the Fixture Ground Wire.
B. Connect the House White or Ribbed Wire to the Fixture Supply Wire (White or Ribbed Side).
C. Connect the House Black/Red Wire to the Fixture Supply Wire (Black or Smooth Side).
D. Wrap each connected wire with **Wire Nut** and carefully stuff all of the connected wires into the **Outlet Box**.
6. Secure the two **Screws** on **Cross Bar** onto the **Outlet Box**, then secure the **Canopy** onto the **Canopy Nipple** with the **Secure Ring**. (See **Picture #8**).
7. Install correct **Bulbs** in the **Sockets** referring to fixture markings and/or labels for maximum wattage. (Included)

