

# REVELATION

by UTTERMOST

## ASSEMBLY INSTRUCTIONS

STYLE# **R22151**

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

*Carefully unpack all lamp parts from the carton.*

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is power off. This lamp must be installed on reinforced Outlet Box.
3. Fasten the **Cross bar** to the **outlet box**. Secure the **Nipple** onto the **Canopy** with **Loop #1**.
4. Adjust chain & wire length as needed. Thread **Quick Link#1** into **Loop #1** on the Canopy, then **Quick Link #2** into Loop #2 on the Lamp Body. Hand tighten until snug.
5. Pass the supply wires through the **Canopy** and the hole in the middle of the **Cross Bar**.
6. The power supply wire consists of three wires, one black wire, one white wire and one silver ground wire.  
Connect the wires as shown. **A.** Connect the House Ground Wire to the Fixture Ground Wire.  
**B.** Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side).  
**C.** Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side).  
**D.** Wrap each connected wire with Wire Connector and carefully stuff all of the connected wires into the Outlet Box.
7. Install the correct **Edison Bulb** (Included) onto the **Socket** referring to fixture markings and/or labels for maximum wattage.
8. Place Glass shade into the Part#1, then threaded the Part#3 to connect the Part#2 and Glass Shade. Hand tighten until snug.

**Your installation is completed now. Restore electricity.**

