

# REVELATION

by UTTERMOST



## Assembly Instruction

### R24688

**1. Take the base B carefully out of the carton, and place it on a flat surface, make sure that the base B will not be damaged.**

**2. Place Plastic stoppers on four corners of the base(B).**

**3. Take the Top(A) out of the wooder crate, and Put it on base(B).**

**To clean; wipe with sofe dry cloth**