

REVELATION
by UTTERMOST
ASSEMBLY INSTRUCTIONS

Assembly Instruction

STYLE NO:R25236

1. Take the parts carefully out of the carton, and place it on a flat surface, making sure that the parts will not be damaged.
2. Screw the iron rod(C) onto the top of the marble assembly (D) properly.
3. Screw the metal top (B) onto the top of the iron rod(C) properly.
4. Place the crystal(A) into the top of the metal top (B)
5. Use either rod (C) or rod (E) depending on desired height. DO NOT USE BOTH.

