

REVELATION

by UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE# R29564-1

Careful unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Thread **Nipple** onto the **Base** and turn clockwise to tighten secured.
3. Install the correct **Edison Bulb** (Included) onto the **Socket** before connecting the plug to the electricity outlet Box.
4. Place the **Glass Shade** between **Part A** and **Part B**, Located the **Knob#1** onto the **Part A** and **Part B** and by turning **Knob#2** clockwise to tighten until snug.
5. Position the fixted **Glass Shade** through the **Socket** on the **Part C**, Located the **Knob#3** onto the **Part C** and by turning **Knob#2** clockwise to tighten until snug.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

