

Parts List:	
Framed Mirror	1x
Mounting Bracket	1x
Screws	4x
Plastic Anchors	4x
Metal Shims (for Non-Anti theft option)	2x

Tools Required:
 Drill
 5/16" Drill Bit (if plastic anchors are used)
 Phillips head screw driver
 Level



Scan for Instruction Video

Mirror Installation Instructions (for Anti-theft)

1. Remove the mounting bracket from the frame by removing shipping tape and by pressing in on the two spring metal flaps in the bottom key hole slots. (see figure 1 & 2)
2. The mounting bracket (see figure 1) should be centered, plumbed and leveled where the mirror installation is desired. The top of the mounting bracket should be 1.25" BELOW where you want the top of the mirror. Attach the mounting bracket to the wall using fasteners that are appropriate for existing wall conditions and materials. The hardware provided (4 screws & 4 anchors) is for convenience, but the installer should use what is deemed appropriate.
3. Now that the mounting bracket is installed you are ready to fit the mirror onto the mounting bracket. Align the shoulder rivets on the mounting bracket just below the neck portion of the key hole slots on the back of the mirror. Gently press in and pull down making sure all 4 shoulder rivets are fully seated in the neck portion of the key slots. (see figure 4)

Mirror Installation Instructions (for a NON Anti-theft scenario)

There are two options to install the mirror when the anti-theft option is not needed.

Option 1. The mount bracket is not to be used for this option. Simply use the appropriate hardware (screws and anchors) and hang the mirror using only the two key hole slots at the top mirror backing. The appropriate wall fasteners will engage with the neck portion of the key hole slots. Key hole slots are provided for horizontal or vertical installation. For horizontal installation, the spring metal flap will need to be disabled (see figure 5)

Option 2. The mounting bracket can easily be used for a NON anti-theft installation. There are two spring metal flaps that prevent the shoulder rivets from sliding out of the bottom key hole slots. The spring metal flaps can be "disabled" by inserting the shims provided in each slot. Slide them in place and then push down as far as they will go. (see figure 3)

Hardware pack

- 4 screws
- 4 plastic anchors

2 metal shims (needed only for Non-Anti-theft option 2)

Care and Maintenance

While in use, maintain the appearance of mirror with glass cleaner.
 Clean the frame with a soft dry cloth.

