

## ASSEMBLY INSTRUCTIONS MODEL NUMBER W26070-1

THANK YOU FOR PURCHASING THIS FLOOR LAMP.  
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

**CAUTION: DO NOT PLUG INTO WALL OUTLET  
BEFORE ASSEMBLY.**

1. Take the parts carefully out of carton, and place them on a flat surface, make sure that the parts will not be damaged.
2. Screw Tube B to Lamp Body A until tight. Carefully pull excess cord through the lamp base during assembly.
3. Screw Tube C to Tube B until tight.
4. Screw Lamp Body D to Tube C until tight.
5. Remove socket ring (G) from lamp holder (E).
6. Place shade onto lamp holder (E)
7. Screw and tighten socket ring (G) onto lamp holder (E).

### IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted.

Do not alter this plug.

### Care and Maintenance

To clean, wipe with a soft dry cloth.

