

**ASSEMBLY INSTRUCTIONS  
MODEL NUMBER W26071-1**

**THANK YOU FOR PURCHASING THIS FLOOR LAMP  
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW**

**CAUTION: DO NOT PLUG INTO WALL OUTLET BEFORE ASSEMBLY.  
UNPLUG WHEN REPLACING THE LAMP BULB.**

1. Take the parts carefully out of carton, and place them on a flat surface, make sure that the parts will not be damaged.
2. Screw tube (B) to lamp body (A) until tight. Carefully pull excess cord through the lamp base during assembly.
3. Screw tubes (C, D, E) together, then screw into tube (B) until tight.
4. Screw lamp body (F) to tube (E) until tight.
5. Remove socket ring (I) from the lamp holder (G).
6. Place shade (H) onto lamp holder (G).
7. Screw and tighten socket ring (I) onto lamp holder (G).

**IMPORTANT SAFETY INSTRUCTIONS:**

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter this plug.

**Care and Maintenance**

To clean, wipe with a soft dry cloth.

