

## ASSEMBLY INSTRUCTIONS MODEL NUMBER W26079-1

THANK YOU FOR PURCHASING THIS FLOOR LAMP  
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW

**CAUTION: DO NOT PLUG INTO WALL OUTLET  
BEFORE ASSEMBLY.**

1. Carefully unpack carton and place all parts on a soft smooth surface. Inventory all parts.
2. Screw tube (B) to lamp body (A) until tight. Carefully pull excess cord through the lamp base during assembly.
3. Screw tube (C) to tube (B) until tight.
4. Screw tube (D) to tube (C) until tight.
5. Screw tube (E) to tube (D) until tight.
6. Remove socket ring (H) from the lamp holder (F)
7. Place shade (G) onto lamp holder (F).
8. Screw and tighten socket ring (H) onto lamp holder (F).
9. Screw Bulb (not included) to socket until tight.

### IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted.

Do not alter this plug.

### Care and Maintenance

To clean, wipe with a soft dry cloth.

Requires 3 Type A 40 Watt max bulbs, not included.

