

ASSEMBLY INSTRUCTIONS

MODEL NUMBER W26082-1

THANK YOU FOR PURCHASING THIS FLOOR LAMP PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW

CAUTION: DO NOT PLUG INTO WALL OUTLET BEFORE ASSEMBLY.

1. Carefully unpack carton and place all parts on a soft, smooth, surface. Inventory all parts.
2. Screw Tube (B) to Lamp Body (A) until tight. Carefully pull excess cord through the lamp base during assembly.
3. Screw Tube (C) to Tube (B) until tight.
4. Screw Tray (D) to Tube (C) until tight.
5. Screw Tube (E) onto tray (D) until tight.
6. Screw Tube (F) to Tube (E) until tight.
7. Screw Socket (G) to Tube (F) until tight.
8. Screw Threaded Rod (H) into Socket (G) until tight.
9. Place the shade (I) onto the top of threaded rod (H) and tighten the finial (J) securing the shade (I).

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter this plug.

Care and Maintenance

To clean, wipe with a soft dry cloth.

Requires 2 Type A 60 Watt max bulbs, not included.

