ASSEMBLY INSTRUCTIONS STYLE NO: W26159-1

THANK YOU FOR PURCHASING THIS FLOOR LAMP. PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

CAUTION: DO NOT PLUG INTO WALL OUTLET BEFORE ASSEMBLY.

(USING 2 PEOPLE FOR ASSEMBLY IS RECOMMENDED)

- 1. Carefully unpack carton and place all parts on a soft, smooth surface. Inventory all parts.
- 2. Thread the cord that is attached to tube (F) into tube (E), then into tube (D), and then into tube (C).
- 3. Attach the clips (B) together.
- 4. Gently screw tube (C) onto base (A).
- 5. Gently screw tube (D) onto tube (C).
- 6. Gently screw tube (E) onto tube (D).
- 7. Gently screw tube (F) onto tube (E).

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY INTO THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.



To clean, wipe with a soft dry cloth.

