



UTTERMOST

# ASSEMBLY INSTRUCTIONS

## STYLE# 21282

**Carefully unpack all lamp parts from the carton.**

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is power off
3. Determine the number of **Rods** to be assembled to the **Fixture Body** according to your hanging height. Pass supply wires through the **Rods**, thread the **Rods** onto the **Coupling** on the top of the **Fixture Body**, hand tighten until snug.
4. Attach one end of the **Quick Link** on the bottom of **Canopy**, and then attach the other end of the Quick Link onto the **Rods**.
5. Pass the supply wires through the **Ceiling Canopy** and the hole middle of the **Crossbar**.
6. Place the **Glass Shade** carefully. Thread the **Metal Sleeve** onto the **socket**. Then lock the **Socket Collar** to secure the Shade. Hand tighten until snug.
7. Install correct **Bulbs** referring to fixture markings and /or labels for maximum wattage. (Included)

**Remark: caution this fixture should not be laid or tipped on it's side**



