

UTTERMOST

ASSEMBLY INSTRUCTIONS

ITEM#:04334

PARTS LIST: A.Anchor(1PC) B.Bracket. C.Screw(1PC) D.Ball Finial(2PCS)
E.Glass F.Candle G.Metal Disk

****Please make sure you have all the parts indicated above before you begin assembly of this item. This item should be assembled on a soft surface to prevent scratching the finish during assembly.**

- 1.Take out all the parts from the Package,Place them in a soft position
- 2.Before you begin to hang the candle.Please make sure all the holes in the wall is at the correct position.Install A(Anchor) into the wall.Put B(Bracket) on the wall,Fixed by C(Screw).It will use 1piece screw.
- 3.Fix the B(Bracket) by two pieces of the Ball Finial (F).
- 4.Put the F(Candle) on the G(Metal Disk),Then Put the E(Glass) onto the G(Metal Disk).
- 5.Adjust the Candle to let the Candle is in level.

