

UTTERMOST

ASSEMBLY INSTRUCTIONS

ITEM#:04340


PARTS LIST: A.Anchor(1PC) B.Screw(1PC) C.Keyhole

****Please make sure you have all the parts indicated above before you begin assembly of this item. This item should be assembled on a soft surface to prevent scratching the finish during assembly.**


- 1.Take out all the parts from the Package,Place them in a soft surface.
2. Install A (anchor) into wall even with the surface . Install B (screw) into anchor leaving the head of screw exposed enough to engage and lock in the key hole.
- 3.Install the screw head in the key hole and lock in place.
- 4.Make sure the wall sculpture is level.

The bird can be swivel to any directions according to customer demands.

This item is can be used for wall sculpture(I) and accessory(II).



I.Wall Sculpture



II.Accessory

