



UTTERMOST

# ASSEMBLY INSTRUCTIONS

STYLE# 21312

**Carefully unpack all lamp parts from the carton.**

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is powered off.
3. Place the **Universal Bar** over the **Canopy** and thread **Mounting Ball** onto the **Mounting Screw** to secure it. Hand tighten until snug.
4. Determine the number of **Rods** to be assembled according to your hanging height. Pass supply wires through the **Rods**. Thread the **Rods** to connect **Nipple #1** and **Nipple #3**. Then thread **Nipple #4** onto the **Fixture Body**. Hand tighten until snug.
5. Pass the supply wires through the **Canopy** and the hole in the middle of the **Universal Bar**.
6. The power supply wire consists of three wires, one black wire, one white wire and one silver ground wire.
7. Connect the wires as shown :
  - A. Connect the House Ground Wire to the Fixture Ground Wire.
  - B. Connect the House White or Ribbed Wire to the Fixture Supply Wire (White or Ribbed Side).
  - C. Connect the House Black/Red Wire to the Fixture Supply Wire (Black or Smooth Side).
  - D. Wrap each connected wire with Wire Connector and carefully stuff all of the connected wires into the Outlet Box.
8. Install correct **Bulb** to the **Socket** referring to fixture markings and/or labels for maximum wattage. (Included)
9. Place the **Glass Shade** onto the **Metal Cup** carefully.

