

ASSEMBLY INSTRUCTIONS

STYLE# 21314

Carefully unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is power off.
3. Fasten the **Crossbar** to the **Outlet Box**. Thread **Screws** to secure it. Hand tighten until snug.
4. Attach one end of the **Quick Link** on the bottom of **Canopy**, and then attach the other end of the **Quick Link** onto the **Loop**.
5. Determine the number of **Rods** to be assembled according to your hanging height. Pass supply wires through the **Rods**. Thread the **Rods** to connect the **Loop** and **Metal Parts**. Then thread **Metal Parts** onto the **Nipple** of **Fixture Body**. Hand tighten until snug.
6. Pass the supply wires through the **Canopy** and the hole in the middle of the **Cross Bar**.
7. The power supply wire consists of three wires, one black wire, one white wire and one silver ground wire.
 - A. Connect the House Ground Wire to the Fixture Ground Wire.
 - B. Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side).
 - C. Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side).
 - D. Wrap each connected wire with Wire Connector and carefully stuff all of the connected wires into the Outlet Box.
8. Install the correct **Edison Bulb** (Included) onto the **Socket** referring to fixture markings and/or labels for maximum wattage.

Your installation is completed now. Restore electricity.

