

# UTTERMOST

## ASSEMBLY INSTRUCTIONS

21391

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF WHILE POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

*We suggest a licensed professional electrician for installation*

### Installation Steps

1. Turn power off at fuse or circuit box before starting installation process.
2. Carefully unpack your new fixture and lay out all the parts on a clear surface.
3. Thread the Nipple-2 into the Coupling. Slip the Center column and Cap over the Nipple, then secure with the Bushing.
4. Choose the suitable number of stems and install the Stem-1, Stem-2 into the Bushing. Adjust the cord/wire to your desired length and remove excess.
5. Thread the Swivel (or Nipple-1) into the Stem-1 if needed.
6. Insert the nipple of Swivel (or Nipple-1) into hole in Canopy, then place the Support cable (an extra safety feature), the Metal washer and the lock washers over the nipple, then secure with the Hex nut.
7. Thread the Ground screw into the hole of the Circular strap. Secure the Circular strap to the outlet box with the Outlet box screws.
8. Attach the Hook on the end of the Support cable (an extra safety feature) to the Circular strap.
9. Make Wire connections with Wire Connector:
  - The smooth wire (w/ marking) from fixture to Black Wire from power source.
  - The ribbed wire (w/o marking) from Fixture to White Wire from power source.
  - Attach the Ground Wire and house ground wire to the Mounting bar with the green Ground screw.

Carefully tuck wires back into the Outlet Box.

10. Place the fixture Canopy over the two Mounting screws so they protrude through the holes in the Canopy. Thread the Ball nut onto the Mounting screws and continue turning until the fixture is snug against the ceiling.
11. Thread the Decorative leaves into the Tubes.

**Adjust line-up of upper and lower Decorative leaves to make them symmetrical.**

