

UTTERMOST

ASSEMBLY INSTRUCTIONS

21542

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

We suggest a licensed electrician for all fixture installations

Installation Steps

1. Carefully unpack your new fixture and lay out all the parts on a clear surface.
2. Secure mounting bar (B) to outlet box with outlet box screws (E). Thread nipple (F) into mounting bar (B) and secure with lock washer (A) and hex nut (D). Do not thread nipple less than three turns. Attach loop (G) to nipple (F).
3. Assemble the center tube (P) and tube (N) together, and secure with cap (M) and large loop (L). Slide on the fabric shade (O).
4. Adjust chain & wire length needed for your install, remove excess. Connect the chain (J) to the large fixture loop (L) at the top of the fixture using the quick link (H).
5. Slide the screw collar ring (K) and canopy (I) in order over chain (J), lace fixture wires up through the chain (J), and pass wires through the hole in loop (G).
6. Attach the top end of the chain (J) to the loop (G) using the quick link (H). Be sure to close all quick links (H) completely.
7. Make wire connections with wire connector:
 - The smooth wire (w/o marking) from fixture to black wire from power source.
 - The ribbed wire (w/o marking) from fixture to white wire from power source.
 - Attach the ground wire and house ground wire to the mounting bar (B) with the green ground screw (C). Carefully tuck wires back into the outlet box.
8. Attach the canopy (I) over the outlet box and secure with screw collar ring (K).
9. Install the light bulb (not included) in accordance with the fixture's specific **DO NOT EXCEED THE MAXIMUM WATTAGE RATING!**
10. Turn on the power at fuse or circuit box.

