

# UTTERMOST

## ASSEMBLY INSTRUCTIONS

21623

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING FIXTURE.

*We suggest a licensed electrician for all fixture installations.*

### Installation Steps

1. Carefully unpack your new fixture and lay out all the parts on a clean and soft surface.
2. Thread the Outlet Box Screws into the matching holes of the Mounting Bar, and tighten by the Screw Driver and Secure it. Thread the Ground Screw (Green) into the Mounting Bar.

3. Adjust the length of wire needed for your installation, remove excess. Determine the length of Rod needed to be assembled to the fixture as needed for the proper hanging height for installation. Attach swivel if needed to canopy, if you don't need swivel, attach metal rod directly to canopy.

Make Wire connections with Wire Connectors:

-- The smooth wire (w/ marking) from fixture to Black Wire from power source.

--The ribbed wire (w/o marking) from Fixture to White Wire from power source.

-Attach the Ground Wire and house ground wire to the Mounting Bar with the green Ground Screw.

Carefully tuck wires back into the Outlet Box.

4. Place the fixture Canopy up to the ceiling and use the mounting screw to tighten the Canopy with the mounting bar
5. Install the light bulbs in accordance with the fixture's specifications. **DO NOT EXCEED THE MAXIMUM WATTAGE RATING.**
6. Turn on the power at fuse or Circuit Box.

