



UTTERMOST

ASSEMBLY INSTRUCTIONS

22144

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

Installation Steps

Carefully unpack your new fixture and lay out all the parts on a clear surface.

- Put the candle sleeve (J) over the socket (K) well, then install the light bulb (not included) in accordance with the fixture's specifications.
DO NOT EXCEED THE MAXIMUM WATTAGE RATING! MUST BE INSTALLED ON A REINFORCED OUTLET BOX.
- Determine the rod length if necessary, then insert the wires through the rods and canopy (E). Assemble the rod (H) together, then assemble the small rod (G) onto the rod (H), after that, assemble the top end of the rod (G) onto the canopy (E) and the bottom end of the rod (H) into the coupling (I).
- Secure mounting plate (B) to outlet box with outlet box screws (A).
- Make wire connections with wire connector:
 - The smooth wire (w/o marking) from fixture to black wire from power source.
 - The ribbed wire (w/o marking) from fixture to white wire from power source.
 - Attach the ground wire and house ground wire to the mounting bar(B) with the green ground screw(C). Carefully tuck wires back into the outlet box.
- Attach the fixture main body onto outlet box by protruding mounting screws(C) through mounting holes on the canopy(E) and secure with ball nut(F).
- Turn on the power at fuse or circuit box.

