



UTTERMOST

## ASSEMBLY AND INSTALLATION INSTRUCTIONS

22159

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

### Installation Steps

- Carefully unpack your new fixture and lay out all the parts on a clear surface.
- Choose the suitable number of stems and install the Stem-1, Stem-2 into the Tube and Swivel.
- Thread the Mounting screws into the matching holes of the Mounting bar, and tighten with the Hex nut. Thread the Ground screw into the hole of the Mounting bar. Secure the Mounting bar to the outlet box with the Outlet box screws.
- Attach the Hook on the end of the Support cable to the Mounting bar.
- Make Wire connections with Wire Connector:
  - The smooth wire (w/ marking) from fixture to Black Wire from power source.
  - The ribbed wire (w/o marking) from Fixture to White Wire from power source.
  - Attach the Ground Wire and house ground wire to the Mounting bar with the green Ground screw.
 Carefully tuck wires back into the Outlet Box.
- Place the fixture Canopy over the two Mounting screws so they protrude through the holes in the Canopy. Thread the Ball nut onto the Mounting screws and continue turning until the fixture is snug against the ceiling.
- Install the light bulb (Not Supplied) in accordance with the fixture's specifications.
 

**DO NOT EXCEED THE MAXIMUM WATTAGE RATING!**
- Thread the Hex nut-1 onto the Nipple, and thread the Nipple into the Coupling, then secure with the Hex nut-1.
- Slide the Glass, the Plastic washer and the Iron washer onto the Nipple, then secure with the Hex nut-2.
- Slide the Cap onto the Nipple, then secure with the Finial.
- Turn on the power at fuse or Circuit Box. Turn power off before starting.

