

STYLE NO:22217

Parts and Hardware List

A.	Canopy	1PC
B.	Cover Assembly	1PC
C.	Glass	1PC
D.	Cross bar	1PC
E.	Wire Nut	2PCS
F.	Flat Washer	2PCS
G.	Steel Tube	1PC
H.	Outlet box Screw	2PCS
I.	Cover	1PC
J.	Hex Nut	3PCS
K.	Plastic washer	2PCS
L.	Pre-Threaded Pipe	1PC
M.	Finial	1PC

Please make sure that you have all the parts indicated before you begin assembly of this item

Please read Wiring Instructions before you begin assembling and installing your Ceiling Lamp.

WARINIG: BEFORE INSTALLING Make sure electricity supply is shut off to avoid a possible electric shock

Assembly Instructions

1. Carefully remove the parts and hardware from the carton.
2. Attach the Cross bar to the ceiling outlet box by using two Outlet box screw. (See Figure1)
3. Install the ground wire in the Universal bar with the green ground screw supplied.
4. Place the white ,ribbed or tinted wire evenly against the white wire from the outlet box and place the black ,smooth or un-tinted wire evenly against the black wire from the outlet box .(Connecting the Wire-See Figure2)
5. After the wires are connected,tuck them carefully inside the outlet box . (See Figure1)
6. Attach the Finial (M) to the Canopy (A) and secure by turning a clockwise direction.
7. Install 3 light bulbs into the sockets of the fixture. Each bulb is not exceeded 60 Watts. Bulbs sold separately.
- 8.Attach steel tube to the cover ,glass ,washer to steel tube then secure with Cover Assembly. (See Figure 3)

