DECORATIVE ACCESSORIES AND ACCENT FURNITURE

UTTERMOST

## **ASSEMBLY INSTRUCTIONS**

## ITEM # :22255 IMPORTANT : TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION Carefully unpack and identify all parts before assembly.

- 1.Be sure the power to the installation point is off.
- 2.Pull the power supply wires out from the outlet box, and mount the cross bar to the outlet box using mounting screws.
- 3.Attach the power supply wires to the fixture lead wires by connecting black to black, and white to white. Attach the power supply ground wire from the outlet box and the fixture ground wire from the fixture to the green ground screw on the mounting bracket or connect both wires together using the correct size of wire connectors.
- 4.Install the canopy over the nipple with hexnut & washer and install ball A onto the nipple and secure with ball finial.
- 5.Screw center stem into hex coupling.
- 6.Install glass shade(J) onto centre stem(G) by fastening hexnut.
- 7.Fix cap B onto center stud by fastening with finial.
- 8.Install bulbs(not included). See label located at socket area for type and maximum allowed wattage

