



UTTERMOST

## ASSEMBLY AND INSTALLATION INSTRUCTIONS

### 22534

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

### Installation Steps

1. Turn on the power at fuse or Circuit Box. Turn power off before starting.
2. Carefully unpack your new fixture and lay out all the parts on a clear surface.
3. Position the Circular strap through the fixing holes onto the wall and make marks, drill pilot holes for Wood screws into the wall, then insert the Plastic anchor into the holes.
4. Secure Circular strap to Outlet box with Outlet box screws, then secure the outlet box with wood screws into Plastic anchors in the wall.
5. Loosen the Screw and Strain relief adjust to the desired height of braid wire, then secure it with Screw and Strain relief (I).
6. Make Wire connections with Wire Connector:
  - The Black wire from fixture to Black Wire from power source.
  - The White wire from Fixture to White Wire from power source.
  - Attach the Ground Wire and house ground wire to the Circular strap with the green Ground screw.
 Carefully tuck wires back into the Outlet Box.
7. Mount the Back plate over the Circular strap and then secure it with Mounting screws.
8. Place the Glass shade over the Socket, then secure with the Socket ring.
9. Install the light bulb (Not Supplied) in accordance with the fixture's specifications.

**DO NOT EXCEED THE MAXIMUM WATTAGE RATING!**

