


UTTERMOST

ASSEMBLY INSTRUCTIONS


				STYLE: 22985
Parts/Hardware list				
A Top Shelf	1PC	E	Bottom Shelf (Empty)	1 PC
B Connectors	4 PCS	F	Ribbed Tube (Short)	4 PCS
C Threaded Rod	4 PCS	G	Stretcher	1 PCS
D Ribbed Tube(Long)	4 PCS	Н	Feet	4 PCS
Mirror(for Top shelf)	1PC		Tempered Glass (for bottom)	1 PC
Felt(for top mirror)	6PCS		Screws	4 PCS
Fi (——В	I	Finial	1 PC
量		J	Felt pads	4 PCS







2. Place the Top Shelf (A) upside down on a flat & soft surface, and then lift it a little bit at one coner and insert 1 screw from the screw hole at the side of the bottom, then tighten one Connector (B) at the other side until secure. Repeat this step to secure all the other three Connectors (B) with the Top Shelf (A).



- 3. Separately tighten the Threaded Rods (C) into the 4 Connectors(B), and let the 4 Ribbed Tubes (Long, D) go through the Threaded Rods (C), making sure that the bottom of the tubes align with the Connectors (B); and then let 4 connectors of the the Bottom Shelf (E,empty) go through The Threaded Rods(C).
- 4. Repeat Step 3 to place the 4 Ribbed Tube (Short,F) onto the Bottom Shelf (E), and then put the Stretcher (G) onto the top of Ribbed Tube (Short,F) and then separately screw the four feet (H) to secure all the parts (D,E,F,G).
- 5. Screw the finial (I) on the center point of stretcher (G)
- 6. Stick the Felt pad (J) on the bottom of Feet(H).





To Clean, wipe with soft dry cloth.