



UTTERMOST

ASSEMBLY INSTRUCTION


ITEM: 23465

PARTS LIST


NO	DRAWING	PARTS NAME	Q'TY	NO	PARTS NAME	DRAWING	Q'TY
A		FLAT WASHER 5/16" X 3/4"	8PCS	1	SEAT FRAME		1PC
B		LOCK WASHER 5/16"	8PCS	2	FRONT LEG		2PCS
C		BOLTS DIA 5/16" X 2"	4PCS	3	BACK LEG		2PCS
D		BOLTS DIA 5/16" X 2-1/4"	4PCS	4	LEFT SIDE STRETCHER		1PC
E		ALLEN WRENCH 5/16"	1PC	5	RIGHT SIDE STRETCHER		1PC
F		WOOD SCREW 1-1/2"	8PCS	6	FRONT STRETCHER		1PC
				7	BACK STRETCHER		1PC

ASSEMBLY BOLTS MAY NEED TIGHTEND AFTER USE

STEP 1



STEP 2



STEP 3

