




UTTERMOST

Assembly Instruction

23510







1. Take the parts carefully out of the carton, and place it on a flat surface, make sure that the parts will not be damaged.

2. Use the bolt and washer to secure the legs(B) to the seat(A)

Hardware and tool included: wrench, bolt, spring washer, flat washer.

3. To Clean, wipe with soft dry cloth.

Parts List

1		Allen key	1pc
2		Bolt 6*25mm	16pcs
3		Spring Washer	16pcs
4		Flat Washer	16pcs