




UTTERMOST

# Assembly Instruction

## 23524



**1. Take the parts carefully out of the carton, and place it on a flat surface, make sure that the parts will not be damaged.**

**2. Use the bolt and washer to secure the legs (B) to the seat (A)**

**Hardware and tool included: wrench, bolt, spring washer, flat washer.**

**3. To Clean, wipe with soft dry cloth.**

### Parts List

1		Allen key	1pc
2		Bolt 6*25mm	16pcs
3		Spring Washer	16pcs
4		Flat Washer	16pcs