
UTTERMOST

ASSEMBLY INSTRUCTIONS


ITEM: 23799

PARTS LIST			
NO	PARTS NAME	DRAWING	Q'TY
1	SEAT AND BACK ASSEMBLY	Q	1PC
2	CYLINDER COVER		1PC
3	BASE ASSEMBLY	*	1PC
4	CASTER	8	5PCS

STEP 1



STEP 2



re- tighten the leg bolts after using a period of time



ASSEMBLY INSTRUCTIONS

ITEM: 23799

STEP 3 Push up the left handle to adjust seat height,. →PULL OUT The right handle can be used to lock the back tilt, also the tilt instrument can be pull out turned to adjust the back tilt. TIGHT/ LOOSE re- tighten the leg bolts after using a period of time