

UTTERMOST



ASSEMBLY INSTRUCTIONS

Assembly Instruction

STYLE:24186

PART LIST

A	TABLE TOP	1PC
B	TABLE FOOT WITH SWITCH	2PCS
C	TABLE FOOT	2PCS



1. Take the parts carefully out of the carton, and then place them on a soft and flat surface, making sure that the parts will not be damaged.
2. Place the Table Top (A) upside down, and place it on a flat and soft place, and then place one pc Table Foot(B) close to the Bottom of Table Top(A), making sure that the screw hole on the Bottom of Table Top (A) and the Foot(B) fit in each other.
3. and then place one pc Table Foot(C) close to the Bottom of Table Top(A), making sure that the screw hole on the Bottom of Table Top (A) and the Foot(C) fit in each other.
4. Insert all Bolts on the Table Feets and do not tighten first, then tighten the bolts together.
5. Turn over the Table and the assembly is completed.

To Clean, wipe with soft dry cloth.