




UTTERMOST

TIP-Resistant Furniture Safety Brackets


- Designed to help prevent furniture tipover.
- Detachable strap allows for easy moving of furniture for cleaning.
- Also helps prevent furniture tipover during minor tremors.

INSTALLATION:




1, Locate a wall stud behind your furniture. position a bracket on the stud approximately 1 below the top of the furniture. Mark & drill pilot hole into the center of the stud with a 3/32" drill bit. Attach a bracket to the stud with the long screws provided.

2, On the back of the furniture, a bracket will need to be attached to the furniture frame at the top. To do this, temporarily move the furniture into its final position & mark the location of the wall bracket on the mark. Mark & drill holes for screws with a 3/32" drill bit. Attach the bracket to the furniture with the short screws provided.



3, Move the furniture into its final position, taking care to line up the wall bracket as shown in the illustration. Tighten strap until snug. Do not overtighten.

IMPORTANT: Check to be sure the wall bracket is firmly screwed into wall stud, firmly attached to the furniture bracket is frame, and the strap is snug.



CAUTION: This product is not to be a substitute for proper supervision. Manufacturer assumes no liability for improper installation or excessive loads placed on screws, brackets or straps.