



UTTERMOST

Assembly instruction STYLE: 24312

Parts List

A	Table top	1PC
B	Leg	4PCS
C	Shelf	1PC
D	Screw	4PCS
E	Flat Washer	8PCS
F	Spring Washer	8PCS
G	Bolt	8PCS
H	Allen Wrench	1PC



1. Lay the Table top (A) on a solid non-abrasive surface such as carpet or cloth as shown below.



2. Attach each Leg (B) to the shelf frame of table top (A) as shown. using (E/F/G) securely tighten all bolts by Allen wrench (H), but do not over tighten the bolts.

3. Assembly is now complete.

PO BOX 55B/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151
www.uttermost.com