



UTTERMOST

Assembly Instruction


STYLE: 24448

Parts list

A	METAL TOP	1PC
B	METAL LEG	1PC
C	TRAY	1PC

Hardware list


COVER NUT	4PCS
GASKET	4PCS
WRENCH	1PC




1. Take metal top parts (A) and metal leg parts (B) carefully out of the carton and place it on a flat surface, make sure that the parts will not be damaged.



2. Put the metal top part on metal leg



3 . Use wrench lock nuts tightly



3 .Put the tray on the metal leg

To Clean, wipe with soft dry cloth.