



UTTERMOST


Assembly Instruction

Item :24542


Parts/Hardware list

A	Side Legs	2PCS	D	Top Shelf	1PC
B	Stretcher	1PC	E	Glass	1PC
C	Bar	2PCS	F	Screws	12PCS
			G	Felt pad	4PCS

1. Take the parts carefully out of the carton, and place them on a flat and soft surface, making sure that the parts will not be damaged.
2. Use 4 Screws (F) to assemble the Side Leg(A) Stretcher(B) and 2 Bars(C) together for one side like below picture (1)
3. Use 4 Screws (F) to assemble the Side Leg(A) Stretcher(B) and 2 Bars(C) together for another side like below picture (2).




(1)



(2)

4. Stick the Felt pad (G) on the bottom of 4 feet on the Side Legs(A).
5. Let down above frame like below picture (3). Use 4 Screws (F) to assemble the Top Shelf(D) and Side Legs (A) together like picture (3).
6. Carefully place the Glass(E)as show in below picture.



(3)

