



UTTERMOST

Assembly Instruction

Item :24862

Parts/Hardware list

A	Legs	3 PCS	C	Screw	6 PCS
B	Table Top	1 PC	D	Washer	6 PCS

1. Take the parts carefully out of the carton, and place them on a flat and soft surface, making sure that the parts will not be damaged.
2. Assemble Legs (A) and the table top (C) together using 6 pcs screws and 6 pcs washers(D).
3. Turn over table.
4. Softly clean & wipe with dry cloth.

