



UTTERMOST

Thank you for purchasing an Uttermost lamp. We hope you are as proud to display this lamp as we were to make it.

- Each lamp is hand finished one at a time, therefore no two are exactly alike.

*Again, thank you for purchasing an Uttermost lamp.*

Assembly Instructions

ITEM#:26409

- 1.UNPACK ALL PARTS FROM CARTON CAREFULLY;
- 2.PLEASE SCREW TUBE(C) ONTO SOCKET ASSEMBLY(B).AND PLACE SHADE(D) ONTO TUBE(C), THEN FASTEN FINIAL(E) TO FIX SHADE(D).

Important Safety Instructions

This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT VIRGINIA 24151  
[www.uttermost.com](http://www.uttermost.com)

