



Assembly Instruction STYLE NO:28078

1. Take the parts carefully out of the carton, and place it on a flat surface, make sure that the parts will not be damaged.
 2. PLACE THE PART (B) TO THE BASE ASSEMBLY (A) PROPERLY.
 3. SCREW THE NUT & ROD (C) INTO THE BASE ASSEMBLY (B), THEN TIGHTEN IT.
 4. ATTACH HARP ("E") TO THE SADDLE ("D")
 5. PLACE THE SHADE ("F") ONTO THE TOP OF HARP ("E"), AND ASSEMBLY "A" SCREW THE FINIAL ("G") CLOCKWISE TO FIX THE SHADE.
 6. Place the finial disc and shade onto the harp, then screw the finial clockwise onto harp until shade is secure.
- CAUTION: IN ACCORDANCE WITH THE UL REGULATION. THE SHADE SHOULD BE OPEN TOP & OPEN BOTTOM AND "CD" IS BIGGER THAN OR EQUAL TO 4-1/2", "R" IS NOT SMALLER THAN 4-3/4" OR MAY CAUSE FIRE. "H" IS 3-1/4"
- TO clean, wipe with soft dry cloth.
- NOTE: THE DRAWING OF THE LAMP BODY IS FOR REFERENCE ONLY